

ELE Hand Auger



ELE Hand Auger

Code: [23-1400](#)

Attributes: [Pins](#) = Used to connect auger head to extension and [tee handle.](#), [Description](#) = ELE Hand Auger

Standards:



3-1/4" Auger Head

Code: [23-1400/10](#)

Attributes: [Weight, lbs](#) = 3.52, [Description](#) = 3-1/4" Auger Head

Standards:



Tee Handle

Code: [23-1400/11](#)

Attributes: [Weight, lbs](#) = 2.03, [Description](#) = Tee Handle

Standards:



Auger Extensions 36"

Code: [23-1400/12](#)

Attributes: [Weight, lbs](#) = 2.34, [Description](#) = Auger Extensions 36"

Standards:



Connector Pin

Code: [23-1400/13](#)

Attributes: [Weight, lbs](#) = 0.22, [Description](#) = Connector Pin

Standards:
