

Tensiometers



Screw-top porous ceramic cup

Code: [514-020/11](#)

Attributes: [Description](#) = Screw-top porous ceramic cup

Standards:



Replacement Dial Gauge.

Code: [514-010/12](#)

Attributes: [Description](#) = Dial Gauge

Standards:



Vacuum dial gauge

Code: [514-020/13](#)

Attributes:

Standards:



Insertion Tool

Code: [514-030](#)

Attributes: [Description](#) = Insertion Tool

Standards:



Tensiometer Extension Tube

Code: [514-042](#)

Attributes: [Description](#) = Tensiometer Extension Tube, Length, mm = 1524 mm

Standards:



Quickdraw soil moisture probe 305 mm

Code: 514-010

Attributes: Tensiometer Type = Quickdraw, Length, mm = 305 mm,
Description = Soil moisture probe, Dimensions (l x w x h) mm = 25 x 9 x 9
inches

Standards:



Quickdraw soil moisture probe 460 mm

Code: 514-012

Attributes: Description = Soil moisture probe, Tensiometer Type =
Quickdraw, Length, mm = 460 mm, Weight, kg = 1

Standards:



Dial-type soil moisture gauge tensiometer 300 mm

Code: 514-020

Attributes: Description = Gauge Tensiometer, Tensiometer Type = Dial-Type,
Length, mm = 300 mm

Standards:



Dial-Type Gauge Tensiometer 450 mm

Code: 514-021

Attributes: Tensiometer Type = Dial-Type , Length, mm = 450 mm ,
Description = Gauge Tensiometer

Standards:



Dial-Type Gauge Tensiometer 600 mm

Code: 514-022

Attributes: Description = Gauge Tensiometer, Tensiometer Type = Dial-Type,
Length, mm = 600 mm

Standards:



Dial-Type Gauge Tensiometer 900 mm

Code: 514-024

Attributes: Description = Gauge Tensiometer, Tensiometer Type = Dial-Type,
Length, mm = 900 mm

Standards:



Jet Fill tensiometer 150 mm

Code: [514-035](#)

Attributes: [Tensiometer Type = Jet Fill](#), [Length, mm = 150 mm](#)

Standards:



Jet Fill tensiometer 300 mm

Code: [514-036](#)

Attributes: [Description = Tensiometer](#), [Tensiometer Type = Jet Fill](#), [Length, mm = 300 mm](#)

Standards:



Jet Fill tensiometer 460 mm

Code: [514-037](#)

Attributes: [Description = Tensiometer](#), [Tensiometer Type = Jet Fill](#), [Length, mm = 460 mm](#)

Standards:



Jet Fill tensiometer 600 mm

Code: [514-038](#)

Attributes: [Description = Tensiometer](#), [Tensiometer Type = Jet Fill](#), [Length, mm = 600 mm](#)

Standards:



Jet Fill tensiometer 900 mm

Code: 514-040

Attributes: Description = Tensiometer, Tensiometer Type = Jet Fill, Length, mm = 900 mm

Standards:



Jet Fill tensiometer 1220 mm

Code: 514-041

Attributes: Description = Tensiometer, Tensiometer Type = Jet Fill, Length, mm = 1220 mm

Standards:



Service Kit

Code: 514-034

Attributes: Description = Service Kit

Standards: