

Plant physiology



Plant Water Status Console, No Tank

Code: [540-310](#)

Attributes: [Description](#) = Plant Water Status Console, No Tank

Standards:



Plant Water Status Console with Tank

Code: [540-315](#)

Attributes: [Description](#) = Plant Water Status Console with Tank

Standards:



Portable Leaf Area Meter

Code: [470-010/01](#)

Attributes: [Description](#) = Portable Leaf Area Meter

Standards:



Chlorophyll Content Meter for Plants & Crops with Battery RS 232 Cable and Software

Code: [470-045](#)

Attributes: [Description](#) = Chlorophyll Content Meter

Standards:



Porometer Complete with Sensor Head 220-240V 50/60Hz, 1 ph

Code: [540-026/01](#)

Attributes: [Description](#) = Porometer Complete

Standards:



Plant Efficiency analyser with control unit & sensor, field neck support & strap, charger,

Code: [470-040](#)

Attributes: [Description](#) = Plant Efficiency analyser

Standards:



Leaf Clips 4mm Pack of 10. (Spare for 470-040).

Code: [470-040/10](#)

Attributes: [Description = Leaf Clips 4mm Pack of 10](#)

Standards:



Porometer Spares Kit Including Electronic Components Pump Cables and Fuses

Code: [540-026/10](#)

Attributes: [Description = Porometer Spares Kit](#)

Standards: