

## Concrete Capping Pads and Retainers




### 4" Retaining Caps

Code: [34-6132](#)

Attributes: [Diameter, " = 5](#), Description = 4" Retaining Caps

Standards: [ASTM C1231](#), [AASHTO T22](#)




### 4" Compression Pads 60 Durometer

Code: [34-6132/10](#)

Attributes: [Diameter, " = 4](#), Description = 4" Compression Pads 60 Durometer

Standards: [ASTM C1231](#), [AASHTO T22](#)




### 4" Compression Pads 70 Durometer

Code: [34-6132/12](#)

Attributes: [Diameter, " = 4](#), Description = 4" Compression Pads 70 Durometer

Standards: [ASTM C1231](#), [AASHTO T22](#)



### 6" Retaining Caps

Code: [34-6134](#)

Attributes: [Diameter, " = 7](#), Description = 6" Retaining Caps

Standards: [ASTM C1231](#), [AASHTO T22](#)



### 6" Compression Pads 60 Durometer

Code: [34-6134/10](#)

Attributes: [Diameter, " = 6](#), Description = 6" Compression Pads 60 Durometer

Standards: [ASTM C1231](#), [AASHTO T22](#)



### 6" Compression Pads 70 Durometer

Code: [34-6134/12](#)

Attributes: [Diameter, " = 6](#), Description = 6" Compression Pads 70 Durometer

Standards: [ASTM C1231](#), [AASHTO T22](#)