

## Accessories to connect ELE compression machines to the flexural/transverse frames

---



### Change over valve assembly kit for 230V, 50/60Hz

Code: [37-0011/01](#)

Attributes: [Description](#) = Flexural Fitting Kit for ADR Auto V2.0, [Voltage Supply](#) = 220-240 V 50 Hz

Standards:



### 100 kN Flexural Fitting Kit ADR Auto for 220 - 240 V AC, 60 Hz, 1 ph

Code: [37-6135/06](#)

Attributes: [Voltage Supply](#) = 220-240 V 60 Hz, [Description](#) = Flexural Fitting Kit ADR Auto

Standards:



### 100kN Flexural Fitting Kit (ADR) Used for Connecting Flexural Frames to ADR Compression Machines.

Code: [37-6138](#)

Attributes: [Description](#) = Flexural Fitting Kit for ADR Touch

Standards: